



FRAGRANCE FAN INSTALL

Install Air Freshener Cartridge and
Replacing Scent Wafers

1

Remove existing air fresheners in restroom.

2

Apply the 2 adhesive strips included to the back of the new Air Freshener. Place above doorway or central part of restroom.

3

Insert 2 scent wafers in UPRIGHT position with a small space between the 2 wafers.*

4

Insert 1 D-Cell battery and close unit.
Batteries will last about 3 months.



*Please add a wafer every month until you have 5 wafers in the unit. On 6th month take out oldest wafer and replace with a new one so you always have 5 wafers in the fragrance fan.



Have Questions? Call Auto-San at (901) 692-3393 or go to <http://www.auto-san.com>.